

# PIONEER

---

# F-9

## MODEL


---

## SERVICE MANUAL


---

#### 4. P.C.BOARD PATTERNS


## Tuner Assembly(GWE-146)



## Fuse Assembly




## A




C

D



**NOTE:**

The indicated semiconductors are representative ones only. Other alternative semiconductors may be used and are listed in the parts list.









## 7. P.C.BOARDS CONNECTION DIAGRAM

A


CONNECTOR Ass'y

AM 9KHz/10KHz  
SELECTOR Ass'y


KEY SWITCH Ass'y

STATION INDICATOR Ass'y  
(GWX-588)





DISPLAY Ass'y (GWX-587)




TUNER Ass'y (GWE-142)




FM/AM SELECTOR Ass'y






# External Appearance of Transistors and ICs


2SK168




PA3007




2SK34




PA5002  
μPD4069C




2SK61




PA4006




2SA872A




HA1138  
IR2E01




2SA1100  
2SC2575




TC9137P




2SB834




TD6301P




2SC461  
2SC535




TD6104P



μPC1163H



P001



HA1201  
PA5001

